

Apple Imagewriter Printer Unpacking Instructions Wide Carriage



We know you are eager to start using your new Imagewriter Printer. But before you do, please take a few minutes to follow these important instructions.

- Please save your Limited Warranty Card for future information.
- Save your packing materials for possible future use.
- **Do not turn on your equipment until you are instructed to do so.** This is to protect you and your equipment.

To Unpack the Accessory Kit:

1. Remove the printed material and the cable(s).

To Unpack the Printer Carton:

1. Open the printer carton by cutting the tape.
2. Remove the cardboard sheet. Beneath it, you will find the power cord, ribbon cassette, and forms rack separator. Pull them from the cardboard backing and unwrap them.
3. With both hands, grasp the end caps and lift the printer out of the carton. (see Figure 1.)
4. Place the printer on a level surface. Slip your hand under the printer to support it. With your free hand, pull each end cap away from the printer.




FIGURE 1

5. Remove the printer from the plastic packing bag. Remove the strapping tape and plastic covering from the carrier cover.
6. Check all of the items from each box against the Packing List.
7. Refer to Figure 3. Lift the carrier cover and remove insert.



FIGURE 2

8. Press your thumb against the front of the carrier cover as you see in Figure 2. Push the carrier cover upward and lift it off of the printer.
9. Reach inside the printer and remove the two black plastic coils (printhead shipping retainers) surrounding the printhead as shown in Figure 3.




FIGURE 3
REAR VIEW

10. Snap the carrier cover back into place and insert the paper separator into the two holes on top of the paper cover, and insert the forms rack separator into the two short slots at the back of the printer. Your printer is now ready to be set up and tested. Please see the manuals included in the Accessory Kit for further instructions.

Your wide carriage Imagewriter Printer is identical in operation to your standard carriage Imagewriter. The "Keep This Copy For Reference" sheet, included in the printer carton, explains how to attach the paper separator and the forms feed (rack) separator while describing the line lengths relative to the wide carriage printer.